

# Thank for purchasing Clear Armour

## The Ultimate Touch Screen Protection

Clear Armour knows that to ensure the lives of the tools that we need every day do not end unexpectedly we need to care for them in the best possible way. Clear Armour have devised a way to apply most effective protection available from 3M to the latest technology on the market - touch screens.

Incorporating 3 layers of highly developed polymers Clear Armour protective film not only protects touch screens from harmful scratches but also enhances you phone's look and operational feel.

Clear Armour is dedicated to offering ultimate solutions so you can get the performance and enjoyment from your digital equipment.

All the best,  
The Clear Armour Team

# Clear Armour Replacement Guarantee

The Replacement Guarantee is that if your Clear Armour ever becomes scratched, torn or damaged in any way while protecting your device, we will replace the Clear Armour for free, for life of your device.


All Clear Armour products are fully guaranteed against defects in materials or workmanship. Our Replacement Guarantee does not cover product damages that may have result from normal wear and tear or misuse/abuse of the product. Clear Armour will not be liable for any indirect, incidental, or punitive damages arising from the use of this product.

Installation errors are not covered by the Replacement Guarantee. This includes bubbles under the Clear Armour film, as well as incorrect alignment of the shield on your device or the application of the wrong Clear Armour product to a particular device. Please read the application instructions carefully before installing your Clear Armour.

## Fitting Instructions



**The Ultimate Touch Screen Protector**

Instructional video also on 

## Step 1

Place two drops of normal dishwashing liquid into pump spray bottle containing 100ml of tap water. (Make sure the bottle has not been used previously for anything with chemicals or solutions of any kind)

Make sure that you have a clean, well lit working environment and that your hands washed too.

Turn your phone off.

Clean the iPhone surface thoroughly with the microfibre cloth provided.

**IMPORTANT: Make sure the surface is perfectly clean. Any material caught between Clear Armour and the phone's surface will cause imperfections in the finished product.**



## Step 2

Spray your fingers with the application solution. This is so no fingerprints are left on the film.

Peel back the film from the backing paper. Spray the solution onto the adhesive side of the film. Align the film on the phone.

Once you are happy with the alignment wrap the micro-fibre cloth around the squeegee and begin to work the solution out from beneath the film.

The cloth lets the squeegee move over the film easier and will soak up any excess solution.

Gently work from the centre of the phone outwards.

## Step 3

If you do notice any imperfections in your application you can lift and reapply the Clear Armour within a few minutes of your initial application, remember to wet your fingers and reapply more solution onto the back of the film before repositioning.

Again work the solution and air bubbles out from underneath the Clear Armour.

There will be some white-ness left on the phone's screen this will disperse in 12 hours and any bubbles will disappear after 48 hours.

**IMPORTANT: Do not place any cases back on the device for a period of 36 hours after Clear Armour has been installed or the film will lift on the edges.**